

From innovation to commercialisation



FSTG Formulation 4.0

13 December 2018

DESIGN OF EXPERIMENT AND MODEL DEVELOPMENT ON THE PROSPECT CL - SCALE UP FACILITY

Dr Katharina Roettger

Senior Research Scientist, CPI



THE PROJECT TEAM



CPI

John Carroll
Caroline Kelly
Silvia Keppler
Katharina Roettger
Alex Smith
Mark Taylor
Georgina Wadsley

Perceptive Engineering Ltd

Matthew McEwan
Eduardo Lopez
Montero

University of Birmingham


Federico Alberini
Peter Fryer
Sofia Matralli
Min Zhang

University of Leeds

Maryam Asachi
Elaine Martin

University of Edinburgh

Andrew Schofield
John Royer
Wilson Poon



THE CENTRE FOR PROCESS INNOVATION

Home to four
NATIONAL CENTRES



CROSS-SECTOR INDUSTRY NEED

PREDICTIVE DESIGN

Faster Innovation

Faster, more reliable approaches to get to an ideal formulation design



MANUFACTURABILITY

Process Innovation

Optimised, reliable system to guarantee the ideal delivery of a formulated product

4IR CAPABILITY


Innovation Enabler

A critical foundational component for knowledge management and problem solving

Need for a better understanding of how to **make and control** complex liquid formulations in manufacturing and scale-up

...to allow for more predictive design thinking and enable the delivery of **faster innovation** and **productivity**

ADVANCED PROCESS CONTROL



THE PROSPECT CL PROJECT

PROSPECT CL



Proving of real-world, scalable, predictive tools and technologies for complex liquids




The dynamics of
manufacture

Enabling predictive
scale up



SCALED VESSELS
(1-1000L)
AND FLOW LOOP



ANALYTICAL
INSTRUMENTS
AND SENSORS



4IR ENABLED
CONTROL
SOFTWARE

Validate new sensor
technologies


Develop process
analytical techniques



THE SCALE-UP RIG




Example configurations:




Vessels increasing in size from 1-1000l, flow skid contains pumps and additional sensors (p, T, pH, conductivity, flow)
Operating temperature 4 - 50°C in standard mode, future 4-90°C. Operating pressure range 0-6 barg.


PROCESS ANALYTICAL TECHNOLOGY



FBRM and Particle Viewer
Chord length distribution
and micrographs
FBRM measurement range
0.5 to 2000 μm




Insitec
At-line laser diffraction measurement
Measurement range 0.1-2500 μm




Hydramotion Rheojet
Operates 250 and 2500 Hz
Measurement range 1-100,000 cP

THE DIGITAL INFRASTRUCTURE




- § Control system capable of monitoring and controlling product quality attributes
- § Smart data fusion for process parameters and PAT output
- § Capability to use process models for real time prediction of process parameters
- § Capability to detect process abnormalities in “real time” through model based fault detection

PREDICTIVE SCALE-UP/SCALE-DOWN APPROACH



PREDICTIVE SCALE-UP/SCALE-DOWN APPROACH




THE MODEL SYSTEM AND DOE PARAMETERS




Model system: High internal phase emulsion (HIPE) of water droplets stabilised with polyglycerol polyricinoleate (PGPR).

DoE: Combined mixture-process design considering oil/water ratio, PGPR content, stirrer speed, temperature and water injection rate.

Confocal images show the variability of the system:




DESIGN OF EXPERIMENT RESULTS




- § Main factors stirrer speed, water addition rate, temperature and mixture
- § Significant impact of combined factors, e.g. interaction of stirrer speed and oil
 - § **This is confirmed by PRBS experiments and model predictive controller (MPC)**
- § Other experiments showed that understanding the shape of particle size distribution is crucial for creating a meaningful model – the D90 alone leads to inaccurate predictions
- § **Scale-up shows that DOE model seems to be predictive of behaviour on pilot plant scale**

SCALE-UP/SCALE-DOWN APPROACH




SCALE-UP ON THE PROSPECT CL RIG



Stirrer speeds (rpm)	1 L vessel			10 L vessel		
	1355 (50%)	2033 (75%)	2710 (100%)	675 (50%)	1013 (75%)	1350 (100%)
Percentile c (90) No Wt (μm)	7.34	8.18	8.14	6.41	8.42	8.09
Span (-)	1.92	2.02	1.90	1.62	1.93	1.84


SCALE-UP ON THE PROSPECT CL RIG



Successful scale-up from bench-top DOE model to 10 L

- § Control of particle size, viscosity and stability when scaling up/down
- § DOE trends can be confirmed on larger scales – more validation experiments to follow


SCALE-UP/SCALE-DOWN APPROACH



MPC DEVELOPMENT AND VALIDATION




- § Pseudo-random binary sequence (PRBS) experiments for MPC development
- § Control of particle size and viscosity and one step ahead real-time predictions of MPC model
- § **Same trends as observed in the DoE model – DOE is predictive of scale-up process**



SUMMARY AND NEXT STEPS

Summary:

- § Successful scale-up from 100 mL to 10 L
- § Development of MPC for advanced process control
- § Qualitative agreement between DoE and MPC



Next steps:

- § Quantitative validation of DoE scale-up up to 100 L scale
- § Scale-up of MPC through adaptive modelling
- § Test predictive scale-up approach on new model system

THANK YOU

*for more information
please get in touch...*

katharina.Roettger@uk-cpi.com

+44 (0)7786 687861

www.uk-cpi.com

@ukCPI



/ukCPI



/ukCPI



+CentreforProcessInnovation



Centre for Process Innovation Limited

