




 devan
chemicals

Bringing textiles to life 

Development of microcapsules as additives for advanced composites



Innovations in Encapsulation

12 December 2014, London, UK

Roberto Teixeira, Maxime Durka and Alexandre Beirão



www.devan.net

Core business

Bringing textiles **to life**

By creating innovative properties and functionality

Taking into consideration sustainability



BRINGING TEXTILES TO LIFE

www.devan.net



chemicals
devan

Microencapsulation Platform



ALLERGEN CONTROL
TECHNOLOGY



SENSORIAL MANAGEMENT
TECHNOLOGY



THERMOREGULATION
TECHNOLOGY



BRINGING TEXTILES TO LIFE

Allergen Control by using *reactive* microencapsulated probiotic endospores on textiles

Sensorial Management Control by using *reactive* microencapsulated fragrances and body/skin care extracts on textiles



Thermoregulation Control by using *reactive* microencapsulated phase change materials on textiles

Insect Control by using *reactive* microencapsulated natural & friendly repellents on textiles

www.devan.net



Typical Microcapsules @ Devan



Small Size (d: 0.9 4.55μm) and monodisperse microcapsules



BRINGING TEXTILES TO LIFE


www.devan.net



chemicals
devan

Typical Microcapsules @ Devan

Work on the adhesion and wash durability



Controlled affinity and covalent reaction with fibers through available functional groups (shells to fibers).

Patented (WO/2006/117702).

www.devan.net



chemicals
devan

Self-Healing Concept

‘ Self healing material (SHM) is a material that has the built-in ability to fully or partially repair the damage occurring during its life time’

Common goal: mimicking biological systems



Self-healing materials


Intrinsic self-healing systems:

Extrinsic self-healing systems:

- Microcapsules**
- Hollow fibers
- Microvascular systems
- Meltable particles



Microcapsules in Self-Healing



Self-healing concept:

Autonomous: no external stimulus needed

Thermoset materials with microcapsules containing healing agents


Different matrix materials:
epoxy, polyurethanes,
unsaturated polyesters

Self-healing concept using embedded microcapsules (adapted from Kessler, M. R. "Self-healing: A New Paradigm in Materials Design." P. I. Mech. Eng. G-J. Aer. 221 (2007) 479.)




Encapsulation of Biogenic Agents and Yeast extracts using MF Shell


1. Suspension in inert oil
2. Emulsion is formed with addition of water & shell precursors
3. Formation of the shell under temperature treatment



FOOD SOURCE in separated container
Microcapsules containing Yeast extracts



MF Microcapsules dispersed in concrete




*MF microcapsules before mixing
with Cement*



Pictures from “The Magnel laboratory”, UGent



MF microcapsules x 150




Encapsulation of Isocyanates by Polyurea Shell





Polyurea shell

Isocyanate component

Amine component



Shell



Successful Microencapsulation of Isocyanates

Tackled challenges:

- ✓ Functionalisation of capsule shell with different hydrophobic agents to improve the shelf-life of capsules
- ✓ Low core content (60%, in the literature) and short shelf-life





BRINGING TEXTILES TO LIFE

www.devan.net



(devan

Capsules with non-functionalised shell



Isocyanate core content 52%
Smooth microcapsules

L. T. T. Nguyen, X. K. D. Hillewaere, R. F. A. Teixeira, O. Berg, F. E. Du Prez, Polymer Chemistry, Article ASAP

www.devan.net

BRINGING TEXTILES TO LIFE





Devan


Capsules with functionalised shell





Encapsulation of Isocyanates



Cryo-Cut + core wash




**Isocyanate
core content
79 wt%**



Shelf-life of Isocyanate-containing microcapsules

PCR



L. T. T. Nguyen, X. K. D. Hillewaere, R. F. A. Teixeira, O. Berg, F. E. Du Prez, Polymer Chemistry, Article ASAP

als




www.devan.net




(devan

Microencapsulation of Active Ingredients Using PDMS as Shell Material – Encapsulation of multi-thiols



R. F. A. Teixeira, O. Berg, L. T. Nguyen, K. Feher, F. E. Du Prez, *Macromolecules*, Article ASAP.

PDMS Shell Microcapsules - Encapsulation of multi-thiols



R. F. A. Teixeira, O. Berg, L. T. Nguyen, K. Feher, F. E. Du Prez, *Macromolecules*, Article ASAP.


www.devan.net



chemicals
devan


BRINGING TEXTILES TO LIFE

HR-MAS Analysis - Encapsulation of multi-thiols



Top: MC with excess of “thiol PDMS”

Bottom: MC with excess of “vinyl PDMS”.



HR-MAS ¹H NMR of MC prepared with excess of “thiol PDMS”

R. F. A. Teixeira, O. Berg, L. T. Nguyen, K. Feher, F. E. Du Prez, *Macromolecules*, Article ASAP.

Summary

Out of the comfort zone

Comfort

Protection

Health



Self-Healing

Microcapsules with highly reactive ingredients – Knowledge acquired

Isocyanates

Multi-thiols

Self-healing opportunities – Market Exploration

Concrete (www.healcon.ugent.be)

Elastomers (<http://www.sim-flanders.be/project/purepair>)

Epoxies



Acknowledgments



Thank you for your attention



Roberto.Teixeira@Devan-be.com

www.devan.net





 **devan**
chemicals

Bringing textiles to life 